

### Important Information

- Do not log out of the Netflix or Vudu accounts. The device will need to be brought back to the Library to be relogged in
- You will not be able to add streaming channels or rent/purchase TV shows or movies on this device
- When returned, the Roku Express will be reset to initial settings
- If remote control does not work, check batteries

---

**Overdue fine:** \$1.00 per day

Please return the Roku to the Check-Out Desk inside the library. **Do not return the Roku in the book drop.**

---

Questions? Contact the Info Desk at 847-929-5101 or email [info@mgpl.org](mailto:info@mgpl.org).



**MORTON GROVE  
PUBLIC LIBRARY**

6140 Lincoln Avenue  
Morton Grove, IL 60053  
847-965-4220 | [mgpl.org](http://mgpl.org)

## MGPL ROKU EXPRESS Quick Start Guide



### What's Included

- Roku Express
- Power Adapter
- Power Cable
- Quick Start Guide
- Roku Remote
- HDMI Cable

### What You'll Need to get Started

- WiFi
- TV with an HDMI input

### Channels

- Netflix
- VUDU
- Kanopy (accessible w/ library card)
- Hoopla (accessible w/ library card)

MORE INFORMATION INSIDE

## Setup Instructions

### Step 1: Connect to your TV

Use the included HDMI cable to connect the Roku to your TV

### Step 2: Connect to Power

Use the included USB power cable and power adapter to connect the Roku to a wall outlet

### Step 3: Position Roku Express

Place the device where you have a direct line of sight to the remote control

### Step 4: Select Input

Use your TV remote input button to select the correct HDMI input. You should see the Roku screen

### Step 5: Connect to WiFi

Use the Roku remote to go to **Settings > Network > Set up connection > Wireless**. Choose your Wifi network and enter the password

## Accessing Content

Use the Home button on the Roku remote to go to the Home Screen

### Netflix

Click on the **Netflix** logo and select the Netflix profile number that corresponds with the number on the Roku case

### Vudu

To see the Library's collection of free Movies & TV Shows click on the **Vudu** logo and select **MY VUDU**. Under **MY VUDU** select **Movies or TV Shows**. You can also watch free movies that contain ads by selecting **Free** under **SPOTLIGHT**.

### Hoopla\*

Click on the **Hoopla** logo. On the next screen follow directions to link to your hoopla account.

### Kanopy\*

Click on the **Kanopy** logo, after you make your selection, follow the directions to link to your Kanopy account.

\* To use these channels you will need to have set up a free account with your library card.